



MTD22 SPARE PARTS KIT 2" MANUAL TOP & BOTTOM DRIVE DUAL MAST SEALER







TOP & BOTTOM SEAL

OPERATOR REQUIRED

UNIFORM CARTONS

2" Spare Parts Kit Part#: MTD22SK

QUANTITY	PART NUMBER	DESCRIPTION
4	N136.AC	Belt, 1340mm x 2" Black
2	27280031	Bearing, Ball 6003ZZ
1	14015	Sprocket, Drive RS35x12T S15.875
1	14037	Sprocket, Follwer RS35x12T
2	AC231300	Roller, Rubber Front 2"
2	10122	Blade, Cutter 2"
2	AC232000	Roller, Rubber Rear 2"
1	10096-1	Spring, Main (Top)
1	10096-2	Spring, Main (Bottom) Chrome
4	10117	Bumper, Rubber M15x7
4	10116	Bushing, Bumper M8x7

Note: Part numbers, descriptions, and pricing are all subject to change without prior notification.

WWW.BESTPACK.COM **VERSION 3.0_0120**





MTD22 SPARE PARTS KIT 3" MANUAL TOP & BOTTOM DRIVE DUAL MAST SEALER







OPERATOR REQUIRED

3" Spare Parts Kit Part#: MTD22SK-0

QUANTITY	PART NUMBER	DESCRIPTION
4	N136.AC	Belt, 1340mm x 2" Black
2	27280031	Bearing, Ball 6003ZZ
1	14015	Sprocket, Drive RS35x12T S15.875
1	14037	Sprocket, Follwer RS35x12T
2	AC331300	Roller, Rubber Front 3"
2	10122-0	Blade, Cutter 3"
2	AC332000	Roller, Rubber Rear 3"
1	10096-1	Spring, Main (Top)
1	10096-2	Spring, Main (Bottom) Chrome
4	10117	Bumper, Rubber M15x7
4	10116	Bushing, Bumper M8x7

Note: Part numbers, descriptions, and pricing are all subject to change without prior notification.

WWW.BESTPACK.COM VERSION 3.0_0120